

Reference Series: How can I control my projector thru the RS232 port? Is there a manual for that?

A description of the RS-232C interface can be found in your projector owner's manual. A copy of the RS-232 command manual can be downloaded here:

⟨[RS_Model_2014_RS232_Command_Spec.pdf](#)⟩

Unique solution ID: #1225

Author: Dave Walton

Last update: 2014-01-23 15:26