

*GY-HM850/890: What are the camera settings for streaming live video from a HM890 to a TriCaster network input to use in a live multi-cam setting? We have set up the camera and the TriCaster Mini on the network and configured the Tricaster inputs but we are only getting a black screen coming through.*

TriCaster supports RTSP/RTP streaming with JVC ProHD cameras. RTSP/RTP is a “pull” mode – Server (TriCaster) needs to be setup to pull video from camera’s IP address. **GY-HM890 settings:**

Streaming: RTSP/RTP

- PW: 1234 (or other)

Camera’s IP address should be known and fixed. Example: 192.168.1.22 **TriCaster settings:**

Protocol: RTSP over UDP

- URL: rtsp://192.168.1.22/stream
- User: prohd
- PW: 1234

*Unique solution ID: #1363*

*Author: Edgar Shane*

*Last update: 2015-11-19 12:52*